


# ASSEMBLY INSTRUCTION


MODEL:18045-995	Boom - 3 seat sofa	Corduroy	Beige
18045-888	Boom - 3 seat sofa	Velvet	Black
18045-987	Boom - 3 seat sofa	Velvet	Blue
18045-980	Boom - 3 seat sofa	Velvet	Beige
18045-989	Boom - 3 seat sofa	Velvet	Pink
18045-894	Boom - 3 seat sofa	Velvet	Green
18045-000	Boom - 3 seat sofa - Teddy	White	
18045-005	Boom - 3 seat sofa	Teddy	Grey / Black
18045-008	Boom - 3 seat sofa	Teddy	Black / Black

## Parts List


Ax1




Ex2



Bx4




Fx2




Cx16





Gx2




Dx1



Hx1



(2)



OBS legs and hardware are packed inside of the sofa!  
Open the zipper on the bottom of the sofa for the parts.